



CQES Removal tool

31ST CQES - 09.2016

For release of crimp connections made with **crimp contacts series CC**

- ① Insert the tool **perpendicular to the rear surface** of the connector body while placing its flat tip inside the dedicated tongue cavity (a) around each contact.

Do not tilt or rotate the tool in the contact cavity, as you may cause unrecoverable damage to the contact retaining clip.

- ② By a slight vertical pressure unlock the contact and recover the crimped connection from the connector cavity by pulling it rearwards, then axially remove the tool tip.

